



ZPA NDIR/O₂ Multichannel Analyzer



CAI ZPA Analyzers use NDIR technology to measure CO, CO₂, CH₄, SO₂, and NO and Oxygen by paramagnetic or electrochemical method.

Features

- Multi-Component analyzer—Up to Four NDIR Channels Plus Oxygen
- Measures from low ppm Up to 100% full scale
- Virtually unaffected by moisture interference
- Measures oxygen from 1% up to 100% via either paramagnetic or electrochemical Method
- Outputs: Voltage, Current, RS-485
- Compact size
- CE Mark

Applications

- Continuous emissions Monitoring (CEMS)
- Greenhouse gases
- Gas purity
- Process gas analysis
- Vehicle emissions
- Engine Testing

Options

- Oxygen only version
- External NOx converter
- Automatic Calibration
- Fault Alarm
- High/low Alarm

ZPA NDIR/Oxygen Analyzer

Method of Operation – NDIR

The ZPA NDIR analyzer is based on the infrared absorption characteristics of gases. Using a single infrared beam to measure gas concentrations, this analyzer produces highly stable and reliable results. A single infrared light beam is modulated by a chopper system and passed through a sample cell of predetermined length containing the gas sample to be analyzed. As the beam passes through the cell, the sample gas absorbs some of its energy. The attenuated beam (transmittance) emerges from the cell and is introduced to the front chamber of a two-chamber infrared microflow detector.

Method of Operation – Oxygen

The oxygen channel of the ZPA utilizes either the paramagnetic or fuel cell method to determine the percent level of oxygen contained in the sample gas.

Specifications

IR Analysis Method – Non-Dispersive Infrared (NDIR)

NDIR Components – CO, CO₂, CH₄, SO₂, NO

Detector Type – Microflow

NDIR Ranges:

Gas	Minimum	Maximum
CO	0-200 ppm	0-100%
CO ₂	0-200 ppm	0-100%
CH ₄	0-500 ppm	0-100%
SO ₂	0-200 ppm	0-10%
NO	0-200 ppm	0-5,000 ppm

Range Ratio – 10:1

Oxygen Analysis Method – Paramagnetic or Fuel Cell

RO₂ Ranges – 0-5% or 0-25% Full Scale

Response Time (IR) – 90% of Full Scale within 30 seconds **Depending on Cell Length, Flow Rate and Time Constant

IR Sample Cell – Stainless Steel

Resolution – Typically 0.1% of Full Scale

Repeatability – Better than 0.5% of Full Scale

Linearity – Better than 1.0% of Full Scale of Factory

Noise – Less than 1% of Full Scale Range

Zero and Span Adjustment – Via front panel or remote

The detector is filled with the gas component of interest and consequently the beam experiences further energy absorption. This absorption process increases the pressure in both of the chambers. The differential pressure between the front and rear chambers of the detector causes a slight gas flow between the two chambers. This flow is detected by a mass-flow sensor and is converted into an output signal.

The oxygen level is displayed on the LCD panel in percent concentration.

Sample Flow Rate – 0.5 LPM

Purge Gas Flow Rate – 1 LPM

Outputs Available – RS-485 (MODBUS protocol), 0-1V / 4-20 mA

Digital Inputs – 9 maximum optically isolated signals for range switching, begin auto calibration, output signal hold, reset average value

Digital Outputs – 15 relays maximum, each is 1 form C for range ID, instrument failure, cal failure, cal in progress, high/low alarm limits, solenoid valve activation, external pump on/off

Display – Back lit LCD

Sample Temperature – Up to 50°C, Non-condensing

Ambient Temperature – -5 to 50°C

Ambient Humidity – Less than 90% RH (Non-condensing)

Fittings – ¼-inch NPT

Power Requirements – 100 to 240 VAC, 50/60 Hz, 100 VA

Dimensions – 5¼" H x 19" W x 15" D,

Weight – Approximately 18 lbs. (Depending on configuration)

Specifications subject to change without notice.



California Analytical Instruments
1312 West Grove Ave., Orange, CA 92865
Phone: 714-974-5560 • Fax: 714-921-2531
www.gasanalyzers.com